

There are two bracket options for open cassette blinds, face fix and top fix. (as shown on the right)



Face Fix Bracket



Top Fix Bracket

### Fitting the brackets


For a blind up to 1 metre wide attach two brackets fitted approximately 75mm (3") from each end of the blind (fig.1). Any intermediate brackets should be spaced evenly between these and as a general rule:

Up to 1m = 2 brackets

1m to 2m = 3 brackets

2m to 3m = 4 brackets

Over 3m = 5 brackets



The bracket release lip on the bracket must face the back of the blind.



Mark the hole positions before drilling and plugging if necessary. Use two screws in each bracket ensuring that the brackets are level. Remember to allow room for the blind to clear any obstacles when deployed, e.g. door or window handles.

### Fitting the cassette

Once all the brackets are in place offer the blind to the brackets. With the cassette tilted away from you locate the front lip into the bracket and push upwards to click the cassette into the back lip of the bracket.

